

Snake River Electronics Glue Addendum



Description:

Due to changes in shipper requirements, we are no longer shipping cans of liquid adhesive with any of our systems.

Tools & Materials Required:

We are now recommending **3M Super 77** spray adhesive. It is available at Walmart and most local hardware stores. It is very inexpensive and easier to use than the liquid we used to ship. Since it is in a spray can there is NO waste.

You will also need common isopropyl alcohol.

Procedure:

Prepare the tank area where the foil tape is to be placed by rubbing down the area with common isopropyl alcohol.

Remove the paper backing from the foil tape strips and place them onto the tank in the designated areas (refer to appropriate sensor installation instructions). Smooth out trapped air bubbles.

Remove the paper backing from the copper pads. Place a copper pad onto each of the two foil strips.

After you have installed the copper pads you can spray the adhesive around the edges of the foil. Using it this way it acts as a sealer. You can if you wish spray over all of the foil and copper but it is only necessary on the edges of the foil.